

TOOLS YOU WILL NEED TO FORM & POUR A CONCRETE SLAB

FOR FORMING

- Drill driver or hammer
- 2 pound hammer
- Laser Level
- String
- 2.5" Deck screws or 16D nails
- Tape measure
- Pencil
- Forming boards
- Forming Stakes

FOR POURING

- Straightedge
- Bull Float
- Kumalongs / Rakes
- Mag float
- Laser Level / Grade stick
- Rubber boots
- Gloves
- Chute extension (optional)
-

NOTES

CONCRETE YARDAGE FORMULA

For 4" Slab: $L \times W / 81$

For 5" Slab: $L \times W / 65$

For 6" Slab: $L \times W / 52$

Or use my Concrete Calculator

REMINDERS

If you desire a smooth finish
You will also need a:

- Power trowel
- Hand trowel